

IDIOMAS | LANGUAGES

Español | ES _____ 2

English | EN _____ 9


Soporte para móvil

Gracias por elegirnos

Gracias por elegir los productos de soporte de teléfono móvil de Ossby, con el fin de utilizar mejor este producto, por favor lea el manual cuidadosamente.


Perfil del producto

1. Tapón izquierdo y derecho
2. Tapón superior
3. Sistema de rotación de paneles
4. Perilla de ajuste
5. Sistema de rotación del soporte
6. Diámetro de la pinza
7. Tornillo de fijación de la pinza




Descripción del producto


Este producto es un soporte para teléfono móvil fijado mecánicamente. Fijar el dispositivo de teléfono móvil mediante el ajuste del tornillo, firme y estable. El soporte del teléfono se instala en hueco de la potencia de la bicicleta, ocupa poco espacio y se instala rápidamente. El ángulo de inclinación del soporte del teléfono se puede ajustar a través del eje móvil (por favor refiérase a la sección de instalación y uso para más detalles en el manual). El soporte del teléfono es compatible varios tamaños de teléfono.




Instalación




En esta sección detallamos los ajustes recomendados para disfrutar de tu soporte para móvil. El correcto ajuste del soporte es necesario para la seguridad de tu móvil en tu Ossby GEO.




1. Retire la cubierta de plástico del juego de dirección de la potencia de la bicicleta.




2. Instala en él el soporte de teléfono.




3. Fíjalo con una llave (la inclinación del soporte del teléfono puede ajustarse cuando el tornillo de fijación está suelto, y se fijará después de apretarlo)




4. La instalación del soporte del teléfono ha finalizado.



5. Desenrosca los ajuste del soporte del teléfono hasta la posición adecuada



6. Fija el teléfono en el soporte y aprieta las roscas.



C/ Sierra de Guadarrama 30
28500 Arganda del Rey Madrid
+34 919 299 347
info@ossby.com


Phone Mount

Thanks for choosing us

Thank you for choosing the Ossby mobile phone holder products, in order to better use this product, please read the manual carefully.


Product profile

1. Left and right stopper
2. Top stopper
3. Panel rotation system
4. Adjustment system
5. Support rotation system
6. Diameter of clamp
7. Clamp fixing screw




Product description


This product is a mechanically fixed mobile phone holder. Fix the mobile phone device by adjusting the knob, Firm and stable. Phone holder install on the bicycle stem headset, it takes up less space and install quickly. The tilt angle of the phone holder can be adjusted through the movable shaft (please refer to the installation and use section for details in manual), The phone holder supports various sizes phone.




Installation




In this section we detail the recommended settings to enjoy your mobile phone holder. The correct setting of the cradle is necessary for the safety of your mobile phone in your Ossby GEO.




1. Remove the headset cover on the bike stem.




2. Install the simple assembled bracket on it.




3. Fix it wrench (the inclination of the phone holder can be adjusted when the fixing screw is loose, and it will be fixed after tightengng).




4. The phone holder installation is completed.



5. Unscrew the adjustment knob of the phone holder to the appropriate position.



6. Fix the phone on the phone holder and tighten the knob.



C/ Sierra de Guadarrama 30
28500 Arganda del Rey Madrid
+34 919 299 347
info@ossby.com